


INSTALLATION MANUAL



Product nr: WC4300-5001





WC4900-5001

WC5500-5001

WC6500-5001

WC7500-5001

List of parts

 <p>A1</p>	 <p>B1</p>
 <p>C1</p>	 <p>D1</p>

ASSEMBLY INSTRUCTIONS



Step 1
Mark drill holes



Step 2
Drill holes (4x)




Step 3
Mount **B1** bracket to the wall




Step 4

Attach D1 (4x) screw to display (backside)




Step 5

Hock display onto wall B1 brackets




Step 6

Attach C1 bracket to B1



Step 7

Attach A1 bracket to C1





Monteringsanvisning WC portrait