# **TV-Clip Mount**

## Introduction

You can use the TV-Clip Mount to deploy devices on the top of TV.



## Specification

Parameter	Description
Physical Features	Dimension (W*D*H): 150*73.8*178 mm Carton Meas: 435*328*310 mm N.W/CTN: 9.292kg G.W/CTN: 9.964kg

## **Package Contents**

# Yealink



#### $\textbf{i)} \, \textbf{NOTE}$

As the device is heavy, it is not recommended that it be used on skinny TVs to avoid the device falling or to crush the screen easily.

# Yealink



- 1. Use VESA screws to fix M-1 and MeetingBar A20.
- 2. Push the M-2 along the track of the M-1.
- 3. Remove one Velcro on the M-2.
- 4. Put the bracket on the top of the TV.
- 5. Stick another Velcro onto the back of the TV (Velcro is a one-time use, please clean the back of the TV before sticking), and make sure that the bracket and the back of the TV are tightly positioned against each other.

#### **Device Compatibility**

Mounts Compatibility Lists please refer to Mounts Compatibility Lists.